



Padfone™ Infinity Station (T003P)

Padfone™ Infinity (T003)

User Manual

E7898
First Edition
April 2013

Copyright © 2013 ASUSTek Computers, Inc. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUS Telecom ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Table of Contents

Package contents.....	5
Using your PadFone Infinity	
Basics.....	6
Navigating your PadFone Infinity.....	7
Making calls.....	8
Setting up your contacts list.....	8
Connecting to the world.....	9
Connecting to mobile networks.....	9
Connecting to Wi-Fi networks.....	10
Using Bluetooth.....	11
Using your PadFone Infinity Station	
Basics.....	14
Unlocking your device.....	14
Entering the camera mode.....	14
Tutorial 15	
Home Screen.....	16
Screen Views.....	17
Touching and typing	
Using gestures.....	18
Using the onscreen keyboard.....	19
Using Google voice typing.....	20
Using apps and widgets	
Using apps on the PadFone Infinity.....	21
Launching apps.....	21
Messaging.....	21
Surfing the web.....	22
Managing notifications.....	22
Searching your PadFone Infinity or web.....	25
Taking pictures.....	25
ASUS Splendid.....	26

Watch Calendar	27
SuperNote	28
Using apps on the PadFone Infinity Station.....	30
Managing Apps.....	30
Task Manager	34
File Manager	35
Play Store	38
Settings	40
Music	42
Gallery	43
Camera	47
Email	48
Gmail	50
MyLibrary	52
Local and Maps	55
Polaris® Office	56
App Backup	58
App Locker	60
ASUS Echo.....	61
ASUS Story.....	62
ASUS Studio.....	64
ASUS To-Do	66
SuperNote	67
Watch Calendar	69
Using PadFone Infinity widgets.....	70
Adding widgets	70
Task Manager	71
Using PadFone Infinity Station widgets.....	72
Adding widgets	72
ASUS Battery.....	73

Package contents

Item	PadFone Infinity	PadFone Infinity Station	2-in-1 set
PadFone Infinity	•		•
PadFone Infinity Station		•	•
Power adapter	•		•
PadFone Infinity signal cable	•		•
Headset	•		•
Quick Start Guide	•	•	•
Important Notices	•		•
Warranty card	•	•	•

NOTES:

- ASUS PadFone Infinity and PadFone Infinity Station are purchased separately.
 - Contact your retailer if any of the items is damaged or missing.
-

Using your PadFone Infinity

1

Use your PadFone Infinity to enjoy the latest features and technologies of Android 4.1 (Jelly Bean) operating system. Do work and play on your PadFone Infinity to fully appreciate the tons of interactive applications and features, and the seamless connectivity solutions in data sharing and communication that Android 4.1 has to offer.

Basics

IMPORTANT:

- Before you start, ensure that you have read all the safety information and operating instructions in the **Important Notices** to prevent injury or damage to your device.
 - Refer to your **PadFone Infinity Quick Start Guide** for instructions on installing the SIM card and charging your device.
-

The first time you turn on your PadFone Infinity, you'll see the Welcome screen.

Touch the menu to choose your preferred language and touch **Next Step**. Follow the succeeding instructions to set up your PadFone Infinity.




NOTES:




- You can skip some of the steps and set them up later.
 - You can press the power key for 10 seconds to reset the system.
-

Navigating your PadFone Infinity

After you finish setting up your PadFone Infinity, the Home Screen appears.






At the bottom of your Home Screen, you'll find three navigation icons , , . These icons, which are always available on the system bar, allow you to instantly jump back to the Home Screen, return to a previous page, or launch a recent app.

Icon	Description
	Allows you to go back to the previous screen, until you are in the Home Screen.
	Opens your Home Screen.
	Opens a thumbnail list of your most recent apps. To launch an app, touch the thumbnail image. If you wish to remove a thumbnail app, swipe it to the left or right.



Making calls

To make a call:

1. Touch  on the Home Screen.
2. Touch the keys to key in the number you wish to call.
3. Touch  to dial.
4. Touch  to end the call.

Setting up your contacts list

To set up your contacts, you can do any of the following:




- Touch  then select **Create a new contact**. Follow the succeeding screen instructions to add a new contact.
- Import your contacts from your SIM card into your PadFone Infinity. To import your contacts from your SIM card:
 1. Install the SIM card into your PadFone Infinity.
 2. From the Home Screen, touch  to launch the People app.
 3. Touch **Import contacts**.
 4. Touch **Import from SIM card**. When prompted, select to which account you want to add the contacts.
 5. To import the contacts one at a time, touch to select a contact you wish to import, then touch **OK**. When prompted, touch **OK** to confirm.

Connecting to the world

Connecting to mobile networks

After installing the SIM card, you are ready to use your PadFone Infinity to make/receive voice calls or transmit/receive data. Different countries or regions may have different mobile networks available and you may have to configure your PadFone Infinity to access these networks.

To configure your Mobile networks setting:

1. Do any of the following to go to the Settings screen:
 - Touch  to go to the All apps screen then touch **Settings** .
 - Swipe your finger down from the top of the screen to go to **ASUS Quick Settings** then touch .
2. From the Settings screen, touch **More....**
3. Touch **Mobile networks**.

NOTE:

- For more details about ASUS Quick Settings, refer to the section **Managing notifications** in Chapter 4.
-

IMPORTANT:

- If your PadFone Infinity does not connect to a network, contact your mobile network carrier for assistance.
 - Refer to your **PadFone Infinity Quick Start Guide** for instructions on how to install a SIM card.
-




Connecting to Wi-Fi networks

Wi-Fi wireless networking technology allows you to exchange data wirelessly over a network. To use Wi-Fi, enable the Wi-Fi feature in your PadFone Infinity and connect to a wireless network. Some wireless networks are secured with a key or protected with digital certificates and requires additional steps to set up; others are open and you can easily connect to them.

TIP:

Turn OFF Wi-Fi when you're not using it to help save battery power.

To enable Wi-Fi and connect to a Wi-Fi network:

1. Do any of the following to go to the Settings screen:
 - Touch  to go to the All apps screen then touch **Settings** .
 - Swipe your finger down from the top of the screen to go to **ASUS Quick Settings** then touch .
2. Slide the Wi-Fi switch to **ON**. When enabled, your PadFone Infinity scans for available Wi-Fi networks.
3. Touch **Wi-Fi** to display list of available Wi-Fi networks nearby. Secured networks are indicated with a lock icon.
4. Touch a network name to connect to it. If the network is secured or protected, you are prompted to key in a Password or key in other credentials.

NOTE:

For more details about ASUS Quick Settings, refer to the section **Managing notifications** in Chapter 4.

IMPORTANT:

If your PadFone Infinity finds a network that you have connected to previously, it automatically connects to it.

Using Bluetooth

Enabling or disabling Bluetooth in your device

Bluetooth is a wireless standard used for exchanging data over short distances. Bluetooth exists in many products, such as smartphones, computers, tablet devices, and headsets.





Bluetooth is very useful when transferring data between two or more devices that are near each other.

The first time you connect to a Bluetooth device, you must pair it with your PadFone Infinity.

TIP:

Turn OFF Bluetooth in your PadFone Infinity when you're not using it to help save battery power.



To enable or disable Bluetooth in your PadFone Infinity, you can do any of the following:

- Touch  to go to the All apps screen then touch **Settings** . Slide the Bluetooth switch to **ON / OFF**.
- Swipe your finger down from the top of the screen to go to **ASUS Quick Settings**, touch , and touch **Bluetooth** .

Pairing your PadFone Infinity with a Bluetooth device

Before you can connect to a device, you must first pair your PadFone Infinity to that device. Once paired, the devices stay paired unless you unpair them.



To pair your PadFone Infinity to a device:

1. Touch  to go to the All apps screen then touch **Settings** . Slide the Bluetooth switch to **ON**.
2. Touch **Bluetooth** to display all available Bluetooth devices within range. If the device you want to pair with is not in the list, ensure that its Bluetooth feature is turned ON and set as Discoverable. See the technical documentation that came with the device to learn how to turn its Bluetooth ON and how to set it to discoverable.
3. If your PadFone Infinity has finished scanning before your Bluetooth device is ready, touch **Search for devices**.
4. In the list of available devices, touch the Bluetooth device you want to pair with. Follow the succeeding screen instructions to complete the pairing. If necessary, refer to the technical documentation that came with the device.

Connecting your PadFone Infinity to a Bluetooth device




After you have paired your PadFone Infinity to a Bluetooth device, you can easily reconnect to it again manually, after it is back in range.

To connect:

1. Touch  to go to the All apps screen then touch **Settings** . Slide the Bluetooth switch to **ON**.
2. In the list of **PAIRED DEVICES**, touch the name of the paired device.

Unpairing and configuring a Bluetooth device

To unpair or configure a Bluetooth device:

1. Touch  to go to the All apps screen then touch **Settings** . Slide the Bluetooth switch to **ON**.
2. Touch **Bluetooth** to display the Bluetooth settings.
3. Touch the Bluetooth Quick Settings icon beside the connected Bluetooth device you want to unpair or configure.
4. From the Bluetooth Quick Settings screen, you can do any of the following:
 - Touch **Unpair** to unpair the device.
 - Touch **Rename** to rename the Bluetooth device.
5. Touch  when you're finished.

Using your PadFone Infinity Station 2

Install your PadFone Infinity into your PadFone Infinity Station to extend its battery life and turn it into a tablet device.

IMPORTANT:

- Before you start, ensure that you have read all the safety information and operating instructions in the **Important Notices** bundled with your PadFone Infinity to prevent injury or damage to your device.
 - Refer to your **PadFone Infinity Station Quick Start Guide** for instructions on inserting your PadFone Infinity into the PadFone Infinity Station.
-

NOTES:

- The image used is for reference only and may look different on your PadFone Infinity Station.
 - The Home Screen may update and change with Android OS.
-

Basics

Unlocking your device



To unlock your device, touch and drag the lock icon out of the circle to the open locked icon.

Entering the camera mode

To enter into **Camera** mode, touch and drag the lock icon out of the circle to the camera icon.


Tutorial

Tutorial automatically starts the first time that you install your PadFone Infinity into your PadFone Infinity Station. It offers useful insights about the seamless possibilities of using the PadFone Infinity and PadFone Infinity Station.

To access it again, touch  to go to the All apps screen then touch **Tutorial** .



Home Screen



Screen Views

The screen view rotates automatically when you hold the tablet horizontally to vertically, and vice versa. To enable/ disable Auto-rotate screen, go to **Settings > Display**.

Landscape view



Portrait view



Touching and typing

Using gestures

Use your fingers to launch apps, move icons, select menu items, press buttons, type on the onscreen keyboard, and perform other useful gestures on your PadFone Infinity device's touchscreen.

To key in or type something, touch the part where you need to type and the onscreen keyboard will pop up.


The following table describes more useful gestures.

Gesture	Description
Pinch	Place two fingers on the screen and spread them apart to zoom in and bring them together to zoom out. This gesture can be used in selected apps, including Maps, Gallery, and Browser.
Drag	Touch and hold an icon or item then, without lifting your finger, move your finger on the screen to move the icon or item.
Touch and hold	Touch and hold an item until an action occurs.
Swipe or slide	Quickly move your finger across the screen in one sweeping motion.
Double-tap	Quickly tap twice on the screen to zoom.

Using the onscreen keyboard

You can type text using the onscreen keyboard.

In most apps, the onscreen keyboard appears automatically when needed. In other apps, you can touch where you need to type to open the onscreen keyboard.





While typing on the onscreen keyboard, the keyboard displays suggestions that may match the text that you need. Touch a suggestion to use it.

Using Google voice typing


Google voice typing uses Google's speech-recognition technology, that converts spoken words into text input. You must be connected to the Internet when using this feature.

As you speak, the converted text is underlined and you can continue speaking to keep it, or you can delete it.

To use Google voice typing:

1. Touch text field where you want to type text.
2. Depending on the app you're using, you can do either of the following:
 - If you see the microphone icon  beside the text field, touch it.
 - If the onscreen keyboard is open, touch and hold  then when prompted to **Choose input method**, touch **Set up input methods** and select **Google voice typing**.
3. When you see the microphone icon, speak clearly what you want to type. When you pause, Google voice typing transcribes the text you spoke and displays it on the text field.

TIPS:

- Say "period", "comma", "question mark", or "exclamation point" to type these punctuation marks.
 - Touch the Backspace key  to delete the underlined text.
-

Using apps and widgets


You can seamlessly use applications between your PadFone Infinity and PadFone Infinity Station.

NOTES:

- PadFone Infinity and PadFone Infinity Station are purchased separately.
 - Some downloaded applications may work on your PadFone Infinity but may not work on your PadFone Infinity Station, and vice versa.
-


Using apps on the PadFone Infinity

Launching apps


Touch  to display all your apps. The main apps screen is where you can see all your apps. From the main apps screen you can:

- Touch an icon to launch an app.
- Swipe the screen to display more apps.
- Drag an app icon into the Home Screen.
- See apps compatible with the PadFone Infinity Station.
- Explore widgets.
- Get more apps from the Play Store.

Messaging

Touch  to compose and send a message.

Surfing the web


Touch  to launch the browser and surf the web.

Managing notifications

Notifications alerts you about new messages, calendar events, media service connections, PC sync information, alarms, and more.

Enable the ASUS Quick Settings app to see more and do more from your Notifications area.

NOTES:

- If ASUS Quick Settings is not enabled, go to the All Apps screen, touch  then select **ASUS customized settings** and enable **Use ASUS Quick Settings**.
 - Depending on your sound settings, you will also hear a sound at the same time a notification icon is displayed on the top left of your screen - everytime a new notification arrives.
-

To see your notifications, swipe your finger down from the top of the screen.

ASUS Quick Settings

The screenshot shows the ASUS Quick Settings interface. At the top, it displays the date 'Tuesday January 1, 2013' and the time '08:48'. Below this is a row of icons for Wi-Fi, Mobile Data, Smart Saving, Instant Dictionary, Wi-Fi Hotspot, and Bluetooth. A second row contains an outdoor mode icon, a brightness slider, and an 'AUTO' button. A third row includes a Wi-Fi with lock icon, a volume icon, a settings gear icon, and a 'Clear' button. Below these are two notification cards: 'Smart Saving is ON' and 'Wi-Fi network available'. At the bottom, there is an 'EMERGENCY CALLS ONLY' button.

Touch to toggle between Outdoor mode and Normal mode

Touch to get into Settings screen

Swipe sideways to see more options

Touch to enable Auto screen brightness setting

Touch to respond to a notification or swipe sideways to dismiss


Description



Touch to enable or disable the Wi-Fi connection.



Touch to enable or disable Mobile Data function.



Touch to enable or disable Smart Saving function.



Touch to enable or disable Instant Dictionary app.



Touch to enable or disable Wi-Fi Hotspot function.



Touch to enable or disable the Bluetooth connection.




Touch to enable or disable the GPS function.



Touch to enable or disable the vibrate feature.




Touch to turn the volume's mute mode on/off.



Touch to enable or disable the auto-rotate screen feature.

Searching your PadFone Infinity or web

Use the Google Search bar at the top of your Home Screen to help you find anything that you need from your PadFone Infinity or from the web. To start searching, you can do either of the following:

- Touch **Google** on the search bar then key in your search item. As you key in your search item, Google lists suggestions that may match your search, touch a suggestion to search for it immediately or touch the arrow beside it to add the term into the search field.
- Touch  then when prompted to **Speak now**, speak clearly the item you're searching.

Taking pictures




Use the camera app, taking pictures and videos with your PadFone Infinity is fun and easy.

The camera app works with two cameras, one 1.2 megapixel camera at the front of your device and one 13 megapixel camera at the rear.

The front camera allows you take pictures and videos, while the rear camera allows you to take high resolution pictures and videos. The rear camera also allows you to take pictures in Panorama mode, where you can pan across a subject to create a single picture.


You can view your pictures and videos in the Gallery app.





Touch  on the Home Screen, then touch  to start taking pictures or touch  to start taking video.

ASUS Splendid

ASUS Splendid allows you to easily adjust the display settings.




To use ASUS Splendid:






1. Touch  to go to the All apps screen then touch **ASUS Splendid** .
2. Adjust the screen color temperature and contrast through the **Temperature** and **Enhancement** taps.
3. Touch **Done** to apply the changes.

Watch Calendar

Watch Calendar allows you to add, edit, and delete an event or appointment and sync it through your Gmail account.



To use Watch Calendar:

1. Touch  to go to the All apps screen then touch **Watch Calendar** .
2. To add an event or appointment, touch .
3. Key in the event name, date and time, location and description of the event. To attach a file, touch + and select a file from the Gallery.
4. Touch **Done**.
5. To edit the selected event, touch . Touch  to delete the selected event.

SuperNote

SuperNote is a convenient app used for writing and painting on your PadFone Infinity. You can take notes, send instant messages, draw sketches, create e-cards with audio recordings or diaries with video, and a lot more.

To launch SuperNote, touch  to go to the All apps screen then touch **SuperNote** .




Using SuperNote

To create a new notebook:

1. Touch **New Notebook**.
2. Key in a name for the file and choose the notebook type to start writing on the page.

The following screen describes the SuperNote screen features on your PadFone Infinity.



NOTE:


- For more details using SuperNote on your PadFone Infinity, tap **Tutorial for Phone**.
-

Using apps on the PadFone Infinity Station

Managing Apps

App shortcut

You can create shortcuts for your favorite apps on your PadFone Infinity Home Screen.

1. Touch  to go to the All apps screen.
2. From the All apps screen, touch and hold the icon of the app you wish to move then drag and place the app on the Home Screen.

App info

You can view the detailed app information while you are creating a shortcut for the app. While holding an app from the All apps screen to the Home Screen, the **App info** will appear on the top of the Home Screen page. Drag the app to **App info** to display its detailed information.

Removing App from Home Screen

You can remove app shortcuts from your PadFone Infinity Home Screen. The original app will remain in your **All apps** screen. To remove an app in your Home Screen:

1. Touch and hold an app on your Home Screen until **X Remove** appears.
2. Drag the app to **X Remove** to remove it from the Home Screen.



App Folder

Create folders to organize your applications and shortcuts on your PadFone Infinity Station Home Screen.

1. On your PadFone Infinity Station's Home Screen, touch and drag an app or shortcut onto another app and a folder will appear.
2. Touch the new folder and tap **Unnamed Folder** to rename the folder.



Recent Apps

Recent apps are displayed on the left panel of the Home Screen. You can find detailed information and manage your apps from the Recent Apps list.

1. Touch the **Recent Apps** icon at the bottom of the Home Screen.





2. Swipe up or down the list to view **Recent Apps**. Swipe a recent app to the left or right to remove from the list.
3. Touch and hold a recent app to display the menu. Select to remove app from list or display app information.





Task Manager

ASUS Task Manager displays a list of currently running utilities and applications and their usages in percentages on your PadFone Infinity Station.

1. Touch  to go to the All apps screen.
2. Touch **WIDGETS** to display the widgets menu.
3. Touch and hold **ASUS Task Manager** to display the ASUS Task Manager box on the Home Screen.



4. Touch and hold the widget to display the sizing brackets. Pull the sizing bracket upward or downward to show the complete list of tasks.
5. Tap  beside each running app to close the app. Touch **Close All** to close running apps all at once.



File Manager

File Manager allows you to easily locate and manage your data either on the internal storage device or the connected external storage devices.

To access the internal storage device:


1. Touch  to go to the **All apps** screen.
2. Go to **All Apps** screen, touch **File Manager**, then go to **My Storage**.



3. The Internal Storage (/sdcard/) and any connected external storage devices (/Removable/) are displayed on the left panel. Touch the source icon on the left panel to display the content list, and touch to select an item.



4. Touch the **Return** folder icon to return to the root directory of **My Storage**.




To access the external storage device:

1. Touch the USB or SD card icon on the bottom right corner of your Home Screen to display the notification box.



2. Touch the folder icon to display its contents.



To copy, cut, delete, or share files:

Tick the file you wish to copy, cut, share, or delete and touch the action icon found at the tool bar on the upper right corner of the File Manager screen.



You can also tick the file and drag/drop it to your desired destination folder.



Play Store

Access lots of fun games and tools in the Play Store using your Google account. If you don't have a Google account, please create one.

To access the Play Store:

1. Touch  to go to the All apps screen.
2. From the All apps screen, tap **Play Store** .
3. You need a Google account to access Google Play. If you don't have an existing account, tap **New**.



4. Type your **Email** and **Password** to **Sign in** if you already have an account.



5. After signing in, you can start downloading and adding apps to your device from the Play Store.



NOTES:

- You cannot restore the deleted applications, but you can login with the same ID and download them again.
 - Some applications are free and some might charge you through a credit card.
-


Settings

Settings screen allows you to configure the settings of your PadFone Infinity Station, including **Wireless & networks, Device, Personal, Accounts, and System** settings. Touch the tabs on the left to switch screens and do the configurations.

There are two ways to go to the **Settings** screen.


From the All apps screen:

Touch **Settings** to display the settings menu.




From **ASUS Quick Settings**:

Swipe your finger down from the top of the screen to launch the **ASUS Quick Settings** panel.



Notification Panels

Notification panels will appear under the Quick Setting panel for alerts or updates in apps, incoming emails, and utility status.



IMPORTANT:


Swipe a notification to the right or to the left to remove item from the list.

Music

Touch **Music** on the Home Screen to play your music files. This application automatically collects and displays all the audio files stored in your PadFone Infinity Station and connected external storage devices.

You can shuffle and play all audio files randomly or flip to select an album for your listening pleasure.

Use the buttons on the top to conveniently sort or search your audio files.



- **NOTE:**
The audio and video codec supported by your PadFone Infinity Station:
Decoder
Audio Codec: AAC LC/LTP, HE-AACv1(AAC+), HE-AACv2(enhanced AAC+),
AMR-NB, AMR-WB, MP3, FLAC, MIDI, PCM/WAVE, Vorbis,
WAV a-law/mu-law, WAV linear PCM
Video Codec: H.263, H.264, MPEG-4, VP8


Encoder
Audio Codec: AAC LC/LTP, AMR-NB, AMR-WB
Video Codec: H.263, H.264, MPEG-4

Gallery

Touch **Gallery** on the All apps screen to browse for images or video files. This app automatically collects and displays all the images and video files stored in your PadFone Infinity.

From the Gallery, you can display images in a slideshow or touch to select for image or video files.



You can also use the menu buttons on the upper right corner of the Gallery screen to sort the files by album, by location, by time, by people, or by tags.




Sharing and deleting albums

Touch and hold an album in the Gallery until the Tool bar on top appears.

Using the Tool bar options, you can upload, delete, or share selected albums online.





Share the selected album through ASUS Webstorage, Bluetooth®, or Gmail®




Delete the selected album

Sharing, deleting, and editing images


Touch an image in the Gallery and use the tool bar on the upper right corner to share, delete, or edit a selected image.



Share the selected album through Amazon Kindle, ASUS Webstorage, or Bluetooth®



Delete the selected album




Check the image information, and edit the selected image


CAUTION!

You cannot restore a deleted file.

Gallery widget

The **Photo Gallery** widget allows immediate access to your favorite photos or albums right from the Home Screen.

1. Touch  to go to the All apps screen.
2. Touch **Widgets** to display the widgets menu.
3. Touch and hold **Photo Gallery** until the gallery widget box moves to the Home Screen and displays the **Choose images** menu box.
4. Choose the album or image that you wish to place as a widget on the Home Screen.




Camera


Touch **Camera** from the Home Screen to take pictures or record videos. You can use the front camera or the back camera to take pictures or record videos.

The image and video files are saved to **Gallery**.

Camera mode





Video mode




Email

Email allows you to add several e-mail accounts and conveniently browse and manage your e-mails.

To set up an email account:



1. Touch  to go to the All apps screen.
2. Touch **Email**  to launch the email app.
3. From the email app screen, key in your **Email address** and **Password**, then touch **Next**.
4. Wait while your PadFone Infinity automatically checks your incoming and outgoing mail server settings.
5. Configure the **Account options** and touch **Next**.





6. Provide a name for the account and key in the name you want displayed on the outgoing messages. Touch **Next** to log into your mail inbox.



To add email accounts:

1. Touch  to go to the All apps screen, touch **Email**  and login using the account that you've previously set up.
2. Touch **Settings** on the upper right corner to display the preferences for this account.
3. Touch **Add account** on the upper right corner to add another account.



NOTE:

You can include all your e-mail accounts in **Email**.

Gmail

Gmail (Google mail) allows you to access your Gmail account, receive, and compose e-mails.

To set up a Gmail account:


1. Touch **Gmail** from the **All apps** screen.
Touch **Existing** and type your existing **Email** and **Password**, then touch **Sign in**.




NOTE:

Touch **New** if you do not own a **Google Account**.

2. Wait while your PadFone Infinity communicates with Google servers to set up your account.



3. You can use your Google account to backup and restore your settings and data. Touch  to sign in to your Gmail.




IMPORTANT:

If you have several e-mail accounts in addition to Gmail, use **Email** to set up and access all your e-mail accounts at same time.


MyLibrary

MyLibrary, an integrated interface for your e-book collections, allows you to place your purchased or downloaded e-books into different bookshelves and genres.

Touch  to go to the All apps screen, then touch **MyLibrary**.

IMPORTANT:


- MyLibrary supports e-books in ePub, PDF and TXT format.
 - You may need Adobe Flash® player to open some e-books. Download Adobe Flash® player before using MyLibrary.
-



Reading your e-books

To read e-books:


1. Touch to select an e-book on the bookshelf.
2. Touch the screen to show the tool bar on the top.



NOTES:


- Android initiates the download and installation of necessary resource if you would like to use the text-to-speech function.
 - Tap on the Bookmark list and select the marked page to show the bookmark icon on the upper right corner of the screen.
-

3. Flip pages like a real book or move the page scroll at the bottom.



Making notes on your e-books

1. Touch and hold on a desired word or sentence until the tool menu and the dictionary definition are displayed.




2. Once selected, you either highlight the selected word with a marker, add a note, use text-to-speech function for the selected text, or simply copy the word.
3. Move the selection point to extend the selected region to a whole phrase or sentence if needed.

Local and Maps

Local

Local allows you to easily find places such as nearby attractions, restaurants, coffee shops, or gas stations. It also allows you to check in your current location at a specific time and share this information with others.



Maps


Maps allows you to find establishments, view maps, and get directions. Use the tool bar on the top to get directions or create your own maps.



Polaris® Office

Polaris® Office is a set of interrelated desktop applications that allows you to create, read, and edit documents, spreadsheets, and presentations.


To use Polaris® Office:

1. Touch  to go to the All apps screen.
2. In the All apps screen, touch **Polaris® Office**.



3. Touch any of the following:
 - Touch **Browser** to view the files/folders in the local storage.
 - Touch **Clouds** to add a cloud service account.
 - Touch **Form type** to view all documents by type.
 - Touch **Favorites** to view your favorite files.

Adding new files

To add new files, touch  on the upper right corner of the screen:

- Touch **Document (.doc)** or **Document (.docx)** to start the word processor to edit documents.
- Touch **Sheet (.xls)** or **Sheet (.xlsx)** to start the spreadsheet to perform calculation and manage information.
- Touch **Slide (.ppt)** or **Slide (.pptx)** to start the application to create and share presentations.
- Touch **Text** to create text files.

Adding Accounts

You are allowed to edit your files with Polaris® Office from other accounts, including **Google Docs**, **WSBoxNet**, and **WSDropbox**.

1. Touch **Clouds**.
2. Select a desired service to add.
3. Key in your e-mail account and password and touch **Done** to add the account.



App Backup

App Locker allows you to back up your installed apps and app data on both the internal and external storage, and restore your installed apps and app data after updating your device firmware.

NOTE:

App Backup cannot restore an app that requires an account authentication. If you have problems with such an app, go to Settings > Apps to clear the app data and log in again.

To use **App Backup**:

1. From the All apps screen, touch on **App backup**.
2. Accept the **End User License Agreement**.




3. Read through the Welcome message and touch **Start** to start using App Backup.





To backup an app:

1. Tick the apps you would like to back up and select a **Backup Type** to back up the app data only or both the app and the app data.
2. When done, touch **Backup** on the upper right corner of the screen to start backup.



To restore an app:

1. Touch **Restore List** to display the Restore List page.
2. Touch a backup file you would like to restore.
3. Touch **OK** on the confirmation message to start restoring an app.



App Locker

App Locker allows you to password-protect your apps.

To use **App Locker**:


1. From the All apps screen, touch on **App Locker**.
2. Set up your password.



3. Touch **OK** to activate App Locker.



4. Tick the apps you would like to lock.
5. You can also deactivate App Locker or change the password from **Settings** on the upper right corner.




NOTES:

- Locked apps will have lock icons on the Home Screen.
- You will be asked for your password everytime you access the locked apps.






ASUS Echo

ASUS Echo lets you use your voice to make calls, search for contacts, adjust the device volume, adjust screen settings, switch on/off Wi-Fi/Bluetooth, and more.



To use ASUS Echo:

1. Touch  to go to the All apps screen then touch **ASUS Echo** .
2. Touch  to record a voice command. ASUS Echo will perform an action accordingly.

ASUS Story

ASUS Story allows you to create and share photo stories.

To use **ASUS Story**:


1. From the All apps screen, touch on **ASUS Story**.
2. Touch **Create Story** to create a photo story.



3. Key in the story name and touch **OK**.




4. Select photos you want to add to the story and touch **Done**.





To edit and share a story:

1. Touch a story name from the **ASUS Story** main page.



2. Touch  on the upper right corner of the screen to edit a photo story.



Touch to rearrange the photos



Touch to add a photo


Touch to add a map

Touch to add text

Touch to layout a page

Edit menu

3. Touch  on the upper left corner of the screen then touch  to share a photo story.




ASUS Studio


ASUS Studio is a photo utility that allows you to easily view, manage, edit, and share photos.

To use **ASUS Studio**:


1. From the All apps screen, touch on **ASUS Studio**.



2. Touch a folder name and touch to play all photos in the folder in a slideshow or delete multiple photos all at once.



3. Touch a photo from a folder to edit, tag, delete, or share it.





NOTE:


Photos with same tags can be automatically combined into one album, allowing you to flip through pages like that in a traditional photo album.



ASUS To-Do


ASUS To-Do allows you to take down your to-do things quickly and easily, and manage your time effectively.

To use **ASUS To-Do**:

1. From the All apps screen, touch on **ASUS To-Do**.
2. Touch  to create a folder.
3. Select a folder and touch  to create a to-do item.
Key in a summary, date and time, and other details.




4. To edit a to-do item, touch . Touch  to delete the selected to-do item.



SuperNote

SuperNote is a convenient app used for writing and painting on your PadFone Infinity Station. You can take notes, send instant messages, draw sketches, create e-cards with audio recordings or diaries with video, and lots more.




Using SuperNote

To create a new notebook:

1. Touch **Add a new notebook**.
2. Key in a name for the file and choose the notebook type to start writing on the page.

The following screen describes the SuperNote screen features on your PadFone Infinity Station:



NOTE:

For more details using SuperNote on your PadFone Infinity Station, tap **Tutorial for Pad**.


Watch Calendar

Watch Calendar allows you to add, edit and delete an event or appointment and sync it through your Gmail account.

1. From the All apps screen, touch **Watch Calendar**.
2. To add an event or appointment, touch **New Event**.
3. Key in the event name, date and time, location and description of the event. You can also attach a file by touching ⊕ then selecting a file from the Gallery.
4. Touch **Done** on the upper right corner of the screen.



To edit an event, touch the event name and touch on the right panel.


Touch  to delete the selected event.



Using PadFone Infinity widgets

Adding widgets

Widgets are useful and fun applications that brings information and services conveniently to your Home Screen at-a-glance. You can find them in the Widgets tab in the All Apps screen, ready to be moved into your Home Screen.

To see your widgets, touch  on your Home Screen then touch the Widgets tab at the top of screen.

From the main Widgets screen, you can:

- Drag a widget to another screen.
- Swipe left or right to move between screens and view more widgets.

IMPORTANT:

- You may be prompted to perform additional tasks (such as registration, activation) before you can use a selected widget.
 - If there is not enough room on the screen where you placed a widget, the widget won't get added to that screen.
-

To remove a widget:

- Touch and hold the widget until **X Remove** appears then without lifting your finger, drag the widget into **X Remove**.

Task Manager

Task Manager is an easy and quick way to close running apps. It effectively cleans your cache and frees more cache space for your PadFone Infinity.

To use Task Manager, swipe your screen to the right.




Additional options:

- To resize Task Manager, touch and hold anywhere on the app until the resize border appears. Touch and drag the sizing handle to adjust to your preferred screen size. You can do this to create additional room for more apps.
- To remove Task Manager, touch and hold the app until **X Remove** appears, then without lifting your finger, drag the app into **X Remove**.

Using PadFone Infinity Station widgets

Adding widgets

Use widgets to conveniently access useful and fun applications on your PadFone Infinity Station's Home Screen. You can find them in the Widgets tab in the All Apps screen, ready to be moved into your Home Screen.

To see your widgets, touch  to go to the All apps screen, then touch **Widgets**.

From the main Widgets screen, you can:

- Drag a widget to another screen.
- Swipe left or right to move between screens and view more widgets.

IMPORTANT:


- You may be prompted to perform additional tasks (such as registration, activation) before you can use a selected widget.
 - If there is not enough room on the screen where you placed a widget, the widget won't get added to that screen.
-

To remove a widget:

- Touch and hold the widget until **X Remove** appears then without lifting your finger, drag the widget into **X Remove**.

ASUS Battery

This special widget shows the individual battery status of your PadFone Infinity and PadFone Infinity Station by percentage and color. The more battery power, the brighter the color.

1. Touch  to go to the All apps screen.
2. Touch **Widgets** to display the widgets menu.
3. Touch and hold **ASUS Battery** to display the ASUS Battery app.



4. The notifications panel also display the battery status. The battery status of the PadFone Infinity and PadFone Infinity Station are shown separately. When battery is low, the battery icon turns from blue to red with an exclamation mark. There will also be a warning sound to notify you when the battery is running low.

ASUS®