

HL-L2305W / HL-L2315DW / HL-L2340DW / HL-L2360DN / HL-L2360DW / HL-L2361DN / HL-L2365DW / HL-L2366DW

Quick Setup Guide

Not all models are available in all countries.


The latest manuals are available at the Brother Solutions Center: <u>solutions.brother.com/manuals</u>.



Unpack the machine and check the components



Watch our FAQ Videos for help with setting up your Brother machine: <u>solutions.brother.com/videos</u>.



Drum Unit (Pre-installed)



Inbox/Starter Toner Cartridge



AC Power Cord (only for certain models)



CD-ROM



Quick Setup Guide



Product Safety Guide

Read the Product Safety Guide first, then read this Quick Setup Guide for the correct installation procedure.

Manuals in Spanish for this model are available on the enclosed CD-ROM. (USA only)

Manuales en Español para este modelo están disponibles en el CD-ROM incluido. (sólo en Estados Unidos)

NOTE:

• The components included in the box and the AC power plug may differ depending on your country.

- The available connection interfaces vary depending on the model.
- The illustrations in this Quick Setup Guide are based on the HL-L2365DW.

You must purchase the correct interface cable for the interface you want to use.
USB cable

We recommend using a USB 2.0 cable (Type A/B) that is no more than 2 meters (6 feet).


Network cable


Use a straight-through Category 5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.

Remove the packing materials and install the toner cartridge



Load paper in the paper tray





Select your language (Only for certain models)

- 1. Press ▼ or ▲ to select General Setup, and then press OK.
- 2. Press OK to select Local Language.

4

3. Press \checkmark or \blacktriangle to select your language, and then press **OK**.

Connect the machine to your computer/mobile device

- Windows® PC with a CD-ROM drive, go to step 5A
- Windows® PC without a CD-ROM drive, go to step 5B
- Macintosh, go to step 5B
- Mobile device users with a WPS/AOSS™-supported access point/router, go to step 5C


Configuration using the CD-ROM (Windows[®])

X




NOTE:

If the Brother screen does not appear automatically, go to **Computer (My Computer)**. (For Windows[®] 8: click the 🔛 (**File Explorer**) icon on the taskbar, and then go to **Computer**.) Double-click the CD-ROM icon, and then double-click **start.exe**.




Connection Type

Brother Printing Device Installation





Wireless Network Connection



[Recommended]

Select this option if you have a USB cable to use temporarily for wireless setup.

Select this option if you do not have a USB cable.

Follow the on-screen instructions to continue Finish Installation.

NOTE: If connection is unsuccessful, repeat this step.



Configuration without using the CD-ROM (Windows[®] without CD-ROM drive or Macintosh)

Download the full driver and software package from the Brother Solutions Center. (For Windows[®]) <u>solutions.brother.com/windows</u>

(For Macintosh) solutions.brother.com/mac

After you download the driver and software package, follow the on-screen instructions until the **Connection Type** screen appears. Refer to **5A** *Configuration using the CD-ROM (Windows[®])*.



 $(\widehat{\mathbf{r}})$

WiFi

One-push wireless setup for mobile devices (Wireless models only)

If your wireless LAN access point/router supports automatic wireless (one-push) setup (WPS/AOSS™), you can set up your machine without using a computer.



Press the WPS or AOSS[™] button on your wireless LAN access point/router.

(i) WIFI

Press the **WiFi** button on your machine.

Wireless setup is now complete.

NOTE:

Before you can use your machine with your mobile device, download "Brother iPrint&Scan."

Print using your mobile device

Download "Brother iPrint&Scan" to start using your machine with mobile devices.



Brother support web site http://support.brother.com